INSTALLATION GUIDE – DIY SLIDING WARDROBE DOORS

KIT INCLUDES

Sliding Wardrobe Doors Bottom Track Top Track Floor Packer (if ordered) Screws

TOOLS REQUIRED

Drill with Phillips Head Screw Bit Screwdriver (if wheels required adjusting)



STEP ONE

Screw your top track to the ceiling or bulkhead, using the Phillips screws provided. Screws should be placed every 500mm-600mm



FRONT

STEP TWO

Place the track with the larger lip to the front. Screw your bottom track into the floor.

If you require a floor packer, screw this to the floor prior to installing the bottom track. Screws should be placed every 500mm-600mm

STEP THREE

Now that you have installed the tracks, it's time to insert your doors.

Place the rear door into the opening by tilting the door into the top track first, then carefully lower the door into the bottom track. Repeat the same for the front door.

If you have 3 doors common practice is to install 2 doors on the back track and 1 door to the front track, but this is up to you and your personal preference.





STEP FOUR

Now that your doors are installed. Push one door to the left side and see if it lines up. If there is an uneven gap between the door and jamb, simply use your Phillips head screw driver to adjust the wheel to suit the angle and even the gap. Repeat this step with the second door to the right side of the wardrobe.